

Kit 1107

DAEWOO Lanos, 4-dr Sedan, 97-03


DAEWOO Lanos, 5-dr Hatchback, 97-03

DAEWOO Lanos, 3-dr Hatchback, 98-03



DAEWOO Leganza, 4-dr Sedan, 97-02

DAEWOO Nubira, 4-dr Sedan, 97-99



DAEWOO Nubira II, 4-dr Sedan, 00-02




**480R
754**



480



750



THULE[®]
SWEDEN


ISO 11154-E


xx kg
xx lbs


7 kg / 15,4 lbs


3 kg / 6,6 lbs

Max. 75kg
Max. 165 lbs






80 km/h
50 Mph
130 km/h
80 Mph
40 km/h
25 Mph
km/h
Mph



THULE




+


Kit XXXX
instructions
THULE





x1



x4


x4


x4
x4

480R/754


x1



x4


x4


x4

480


x1


x4


x4

750



x2


x2


x2


x2



x2



x2


x2



x2



x4


x2



x2


x4


x4


x2


x2


x2





115

x4


204






x2


03




x4


x1



Kit




3



1




2




	X
DAEWOO Lanos, 4-dr Sedan, 97-03	22,5
DAEWOO Lanos, 5-dr Hatchback, 97-03	22,5
DAEWOO Lanos, 3-dr Hatchback, 98-03	23
DAEWOO Leganza, 4-dr Sedan, 97-02	32
DAEWOO Nubira, 4-dr Sedan, 97-99	27,5
DAEWOO Nubira II, 4-dr Sedan, 00-02	27,5

1





2





	Y
DAEWOO Lanos, 4-dr Sedan, 97-03	22
DAEWOO Lanos, 5-dr Hatchback, 97-03	22
DAEWOO Lanos, 3-dr Hatchback, 98-03	21,5
DAEWOO Leganza, 4-dr Sedan, 97-02	29
DAEWOO Nubira, 4-dr Sedan, 97-99	26,5
DAEWOO Nubira II, 4-dr Sedan, 00-02	26,5

3

480R















480
1

2


	X inch	X mm
DAEWOO Lanos, 4-dr Sedan, 97-03	34 1/2"	876 mm
DAEWOO Lanos, 5-dr Hatchback, 97-03	34 1/2"	876 mm
DAEWOO Lanos, 3-dr Hatchback, 98-03	34 5/8"	881 mm
DAEWOO Leganza, 4-dr Sedan, 97-02	38 1/4"	971 mm
DAEWOO Nubira, 4-dr Sedan, 97-99	36 1/2"	926 mm
DAEWOO Nubira II, 4-dr Sedan, 00-02	36 1/2"	926 mm

1

2


	Y inch	Y mm
DAEWOO Lanos, 4-dr Sedan, 97-03	34 1/4"	871 mm
DAEWOO Lanos, 5-dr Hatchback, 97-03	34 1/4"	871 mm
DAEWOO Lanos, 3-dr Hatchback, 98-03	34 1/8"	866 mm
DAEWOO Leganza, 4-dr Sedan, 97-02	37"	941 mm
DAEWOO Nubira, 4-dr Sedan, 97-99	36 1/8"	916 mm
DAEWOO Nubira II, 4-dr Sedan, 00-02	36 1/8"	916 mm

SRA




4

DAEWOO Lanos, 4-dr Sedan, 97-03







DAEWOO Lanos, 5-dr Hatchback, 97-03

DAEWOO Nubira, 4-dr Sedan, 97-99



DAEWOO Nubira II, 4-dr Sedan, 00-02





DAEWOO Leganza, 4-dr Sedan, 97-02



5





	X mm	Y mm	Z mm	X inch	Y inch	X inch
DAEWOO Lanos, 3-dr Hatchback, 98-03	190 mm	700 mm	360 mm	7 1/2"	27 1/2"	14 1/8"



GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно


CZ Pokrétla багажníka dokręcaj dokręcaj naprzemiennie.
SK Dofahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenično zategnite
HU Egymástól függgetlenül szorítandó
GR Σφιγγετε εναλλάξ
TR Dönüşümlü sıkın
中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ขึ้นในแบบสลับ

5





	X mm	Y mm	X inch	Y inch
DAEWOO Lanos, 4-dr Sedan, 97-03	200 mm	600 mm	7 7/8"	23 5/8"
DAEWOO Lanos, 5-dr Hatchback, 97-03	200 mm	550 mm	7 7/8"	21 5/8"
DAEWOO Leganza, 4-dr Sedan, 97-02	200 mm	650 mm	7 7/8"	25 5/8"
DAEWOO Nubira, 4-dr Sedan, 97-99	180 mm	650 mm	7 1/8"	25 5/8"
DAEWOO Nubira II, 4-dr Sedan, 00-02	180 mm	650 mm	7 1/8"	25 5/8"

DAEWOO Lanos, 4-dr Sedan, 97-03
DAEWOO Lanos, 5-dr Hatchback, 97-03
DAEWOO Nubira, 4-dr Sedan, 97-99
DAEWOO Nubira II, 4-dr Sedan, 00-02




DAEWOO Leganza, 4-dr Sedan, 97-02



GB/US	Tighten alternately	CZ	Pokřetla bagažníka dokřećaj dokřećaj napřezmiennie.
D	Die Schrauben abwechselnd anziehen	SK	Dofahujte striedavo
F	Serrer alternativement chaque côté	SLO	Privijajte izmenično.
NL	Afwisselend aan de linker- en de rechterkant aandraaien	HR	Naizmjenično zategnite
I	Alternare il serraggio delle viti	HU	Egy mástól függetlenül szorítandó
E	Apretar alternativamente	GR	Σφιγγετε εναλλάξ
PT	Aperte alternadamente	TR	Dönüşümlü sıkın
S	Dra åt växelvis	中文	交替拧紧
FIN	Kierrä vuorotellen	한국어	번갈아 가며 조이십시오.
EST	Pinguldage vaheldumisi	日本語	交互に締め付けてください。
LAT	Pievēciēt pamišus	ไทย	ขันในแบบสลับ
LIT	Užsukinkite pakaitomis		
PL	Śruby dokręcaj naprzemiennie		
RU	Затягивайте попеременно		






6





480R/754



480



750




i




1




2




i



1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		